

## INSTALLATION INSTRUCTIONS for ALL SIG PISTOL ADAPTERS


For use with the following Insight products:

- M3 Tactical Illuminator
- M6 Tactical Laser Illuminator
- LAM Series (IR and Visible)
- M3X Tactical Illuminator
- M6X Tactical Laser Illuminator
- XTI Procyon

### **WARNING:** VERIFY THAT THE WEAPON IS CLEAR AND SAFE BEFORE PROCEEDING

**1.** Verify that all components of the adapter assembly shown in the picture are present.


**2.** Remove the screws, washers, and left and right jaws from the adapter assembly using the included 5/64" hex key.



**3.** Push mount onto frame, and ensure that it is tight to the weapon frame and trigger guard by squeezing together.

**4.** Holding mount to frame, place the right jaw over the trigger guard and adapter.

**5.** Insert washers and screws into through-holes on the right jaw.



**6.** Install the left jaw on the opposite side of the trigger guard.

**7.** Tighten screws with enclosed hex key until mount is fully secured to the frame.

**8.** To remove adapter, repeat steps 3-7 in reverse order.